

System Data Sheet


remmers

Façade hydrophobic
treatment with
Facade Cream 25 [basic]



INSTRUCTIONS FOR USE



①

CLEANING THE SUBSTRATE

Clean the substrate with a moderate pressure jet or steam jet cleaner.



②

IMPREGNATION

Once the substrate is completely dry:
Apply Façade Cream 25 [basic] with the
FC Paint Roller or a flat brush.

Products used

HYDROPHOBIC IMPREGNATION



Facade Cream 25 [basic]

Application rate: approx. 0.15 to 0.20 l/m²
Art. No. 0711

TOOLS



FC Paint Roller

Art. No. 4913

TOOLS



Flat brush

Art. No. 4540