





DE

Montageanleitung
EM WP-EKTA (OPTIONAL)
CRL-iH/A evo max



Deutsch / Änderungen vorbehalten


CRL-iH/A evo max
EM WP-EKTA (optional)



Pos.	Menge	Bemerkung
1	1x	EM WP-EKTA
2	4x	M8x50
3	4x	M8
4	1x	MWTF NTC 5kOHm 0,4m
5	Rolle	10x2


1.





3.

CRL evo max





Montageanleitung EM WP-EKTA für CRL-iH/A evo max



Montageanleitung EM WP-EKTA für CRL-iH/A evo max



Montageanleitung EM WP-EKTA für CRL-iH/A evo max

WOLF GmbH / Postfach 1380 / D-84048 Mainburg
Tel. +49.0.87 51 74- 0 / Fax +49.0.87 51 74- 16 00 / www.WOLF.eu