







Montageanleitung
ERSATZVENTILATOR
CFL 15 / CFL 22
Änderungen vorbehalten!

Installation instructions
REPLACEMENT FAN
CFL 15 / CFL 22
Subject to modifications





①  1x	②  1x
③  1x	④  2x
⑤  2x	⑥  2x ⑦  4x


8  1x	9  1x
10  2x	11  3x


1.	
2.	

3.




4.







6.





7.




8.



9.	
10.	

11.





WOLF GmbH / Postfach 1380 / D-84048 Mainburg
Tel. +49.0.87 51 74- 0 / Fax +49.0.87 51 74- 16 00 / www.WOLF.eu